


Trash Can 31 Gal Owner's Manual

MODEL:
SC31GY2



EAST OAK



Need help starting?

Scan the QR code for installation video guidance.



installation video



Questions? Comments?

Reach out to us for expert support!

✉ support@eastoak.com

🌐 eastoak.com


☎ 1-833-EAST-OAK (USA)

(9am-5pm PST/PDT)



Unlock all the perks!

Start the registration process now for a 3-year warranty.



Step 1:

Found the Unique Product ID on the product.



eastoak.com/warranty

Step 2:

Scan the QR code within 90 days to access our registration page. Fill the Unique Product ID and other required information as instructed.

Complete the registration !



Welcome to the East Oak family!

Stay updated with our latest news and exclusive discounts by following us on social media!



Facebook @eastoakliving
www.facebook.com/eastoakliving



Instagram @eastoakliving
www.instagram.com/eastoakliving/



Youtube @eastoakliving2080
www.youtube.com/@eastoakliving2080

IMPORTANT CAUTION

Once installed, the product cannot be detached. Please strictly follow each step in the installation manual.

- Please check all parts and components to ensure that there are no damages or missing items before starting the construction of the product. If you have any problems or discover any missing parts, please contact customer service at support@eastoak.com
- Some parts may contain sharp edges. Wear protective gloves if necessary during assembly.

ASSEMBLY INSTRUCTIONS

- DO NOT assemble this item alone for your safety. Two people are necessary for smooth and safe installation.
- Item identification: For ease of identification, all parts are labeled to correspond to the step number in which the part is used.

CARE & SAFETY

- Check all panels for tightness before usage.
- It is of utmost importance to assemble all parts according to the directions. Do not skip any step.
- In case of fire, do not attempt to extinguish any burning polypropylene with water.
- Using a stiff brush or abrasive cleaner could damage the box.
- After rain, wipe the box with cloth before opening.
- Do not stand on the lid.
- To prevent the risk of suffocation, do not allow children to play inside the box.
- Exercise caution when moving fully loaded product. This product is not intended for transporting heavy objects.

PARTS LIST



Front Side Board

A X 4PCS




Plastic Hinge

B X 2PCS



Movable Cleaning Tray and Base

C+D X 1PC



Upper Cover Board

J+K X 1PC



Rubber Plug

E X 4PCS



Garbage Sorting Board

F X 2PCS



Screw

G X 2PCS

WHAT'S IN THE BOX


- 6 x Trash Can Assemblies
- 2 x Garbage Sorting Board
- 2 x Plastic Hinge
- 2 x Screw
- 4 x Rubber Plug
- User Manual

1 ASSEMBLY INSTRUCTIONS

Buckle the four panels according to the diagram.



A X 4PCS




2

Remove the Movable cleaning tray from the Base. Put the assembled main body upside down, and buckle the base into it, and then make it upright.

Attention: Keep the arrows of the base and the main body in the same direction.



C+D X 1PC



3

Install the Plastic Hinge(B) onto the panel opposite the opening of the Base with two screws(G).



B X 2PCS



G X 2PCS




5

Installation of Upper Cover Board(J+K)

Align the slot of the buckle of the Upper Cover Board(J+K) with the convex point of the Plastic Hinge and then press it.



J+K X 1PC




4

Install the four Rubber Plugs(E) onto the Upper Cover Board(J+K).



E X 4PCS



6

Push the removable cleaning tray(C) letter down into the base. Install the Garbage Sorting Board(F) according to your needs.




F X 1PC



1 HOW TO SECURE TRASH BAGS

Open the inner lid of the trash can.




3 Organize the excess part of the trash bag.



2 Put on the trash bag.




4 Secure the excess into the groove and pull inward tightly.



secure it in the groove

5

Cover the inner and outer lids.
Press the lid with your hand until you hear a **click** to make sure it is tight.



FEATURES

- UV and Fade Resistance
- Durable and Long-lasting Use
- Easy to Assemble
- Marine-grade Quality Hardware
- Comfortable Side Handles
- Upgraded PP Material to Prevent Bending and Fading
- Great Option for Home Storage and Organization

6

Open the outer lid only for daily use.



WARRANTY POLICY

GUARANTEED 3-YEAR WARRANTY

Thank you for choosing East Oak. This product is covered by our company warranty for up to 3 years from its original purchase date.

CLAIM WARRANTY

If you'd like to claim your product's warranty, register your new product on our website at www.eastoak.com/warranty.

⚠️ WARNING

Cancer and Reproductive Harm
www.P65Warnings.ca.gov.

EAST OAK

✉ support@eastoak.com

🌐 eastoak.com

☎ 1-833-EAST-OAK (USA)